



Jauhatus-nopeus (g/s)	Ajastimen säädön vaikutus (g)					Ajastinta säädettävä haluttuun muutokseen					
	1p	1/4k	1/2k	3/4k	1k	0.5g	1.0g	1.5g	2.0g	2.5g	3.0g
0.50	0.07	0.20	0.40	0.60	0.80	1/2k 1/2p	1 <sup>1</sup> /4k	13/4k 11/2p	21/2k	3k 1 <sup>1</sup> /2p	3 <sup>3</sup> /4k
0.55	0.07	0.22	0.44	0.66	0.88	1/2k 1p	1k 1 <sup>1</sup> /2p	11/2k 21/2p	21/4k 1/2p	23/4k 1p	31/4k 2p
0.60	0.08	0.24	0.48	0.72	0.96	1/2k 1/2p	1k 1/2p	11/2k 1p	2k 1p	21/2k 11/2p	3k 11/2p
0.65	0.09	0.26	0.52	0.78	1.04	1/2k	3/4k 21/2p	11/4k 21/2p	13/4k 2p	21/4k 2p	23/4k 11/2p
0.70	0.09	0.28	0.56	0.84	1.12	1/4k 21/2	3/4k 11/2p	11/4k 1p	13/4k 1/2p	21/4k	21/2k 2p
0.75	0.10	0.30	0.60	0.90	1.20	1/4k 2p	3/4k 1p	1 <sup>1</sup> /4k	11/2k 2p	2k 1p	21/2k
0.80	0.11	0.32	0.64	0.96	1.28	1/4k 1/2p	3/4k 1/2p	1k 2p	11/2k 1p	13/4k 21/2p	21/4k 1p
0.85	0.11	0.34	0.68	1.02	1.36	1/4k 1/2p	3/4k	1k 1p	11/4k 21/2p	13/4k 1p	2k 21/2p
0.90	0.12	0.36	0.72	1.08	1.44	1/4k 1p	1/2k 21/2p	1k 1/2p	11/4k 11/2p	13/4k	2k 1p
0.95	0.13	0.38	0.76	1.14	1.52	1/4k 1p	1/2k 2p	1k	11/4k 1p	11/2k 11/2p	13/4k 21/2p
1.00	0.13	0.40	0.80	1.20	1.60	1/4k 1p	1/2k 11/2p	3/4k 21/2p	1 <sup>1</sup> /4k	11/2k 1p	13/4k 11/2p
1.05	0.14	0.42	0.84	1.26	1.68	1/4k 1/2p	1/2k 1p	3/4k 11/2p	1k 21/2p	1 <sup>1</sup> /2k	13/4k 1/2p
1.10	0.15	0.44	0.88	1.32	1.76	1/4k 1/2p	1/2k 1p	3/4k 1p	1k 11/2p	11/4k 2p	11/2k 21/2p
1.15	0.15	0.46	0.92	1.38	1.84	1/4k 1/2p	1/2k 1/2p	3/4k 1p	1k 1p	11/4k 11/2p	11/2k 11/2p
1.20	0.16	0.48	0.96	1.44	1.92	1/4k	1/2k 1/2p	3/4k 1/2p	1k 1/2p	11/4k 1/2p	11/2k 1p
1.25	0.17	0.50	1.00	1.50	2.00	1/4k	1/2k	3/4k	1k	1 <sup>1</sup> /4k	11/2k
1.30	0.17	0.52	1.04	1.56	2.08	1/4k	1/2k	1/2k 21/2p	3/4k 21/2p	1k 21/2p	11/4k 21/2p
1.35	0.18	0.54	1.08	1.62	2.16	1/4k	1/4k 21/2	1/2k 21/2p	3/4k 2p	1k 2p	11/4k 11/2p
1.40	0.19	0.56	1.12	1.68	2.24	21/2p	1/4k 21/2	1/2k 2p	3/4k 11/2p	1k 11/2p	11/4k 1p
1.45	0.19	0.58	1.16	1.74	2.32	21/2p	1/4k 2p	1/2k 2p	3/4k 11/2p	1k 1p	11/4k 1/2p
1.50	0.20	0.60	1.20	1.80	2.40	21/2p	1/4k 2p	1/2k 11/2p	3/4k 1p	1k 1/2p	11/4k

Jauhatusnopeustaulukko (g/s)																		
5s	6s	7s	8s	9s	10s	11s	12s	13s	14s	15s	16s	17s	18s	19s	20s	21s	22s	23s
2g																		
3g	0.60	0.50																
4g	0.80	0.67	0.57	0.50														
5g	1.00	0.83	0.71	0.63	0.56	0.50												
6g	1.20	1.00	0.86	0.75	0.67	0.60	0.55	0.50										
7g	1.40	1.17	1.00	0.88	0.78	0.70	0.64	0.58	0.54	0.50								
8g	1.33	1.14	1.00	0.89	0.80	0.73	0.67	0.62	0.57	0.53	0.50							
9g	1.50	1.29	1.13	1.00	0.90	0.82	0.75	0.69	0.64	0.60	0.56	0.53	0.50					
10g		1.43	1.25	1.11	1.00	0.91	0.83	0.77	0.71	0.67	0.63	0.59	0.56	0.53	0.50			
11g			1.38	1.22	1.10	1.00	0.92	0.85	0.79	0.73	0.69	0.65	0.61	0.58	0.55	0.52	0.50	
12g				1.50	1.33	1.20	1.09	1.00	0.92	0.86	0.80	0.75	0.71	0.67	0.63	0.60	0.57	0.55
13g					1.44	1.30	1.18	1.08	1.00	0.93	0.87	0.81	0.76	0.72	0.68	0.65	0.62	0.59
14g						1.40	1.27	1.17	1.08	1.00	0.93	0.88	0.82	0.78	0.74	0.70	0.67	0.64
15g							1.50	1.36	1.25	1.15	1.07	1.00	0.94	0.88	0.83	0.79	0.75	0.71
16g								1.45	1.33	1.23	1.14	1.07	1.00	0.94	0.89	0.84	0.80	0.76
17g									1.42	1.31	1.21	1.13	1.06	1.00	0.94	0.89	0.85	0.81
18g										1.50	1.38	1.29	1.20	1.13	1.06	1.00	0.95	0.90
19g											1.46	1.36	1.27	1.19	1.12	1.06	1.00	0.95
20g												1.43	1.33	1.25	1.18	1.11	1.05	1.00
21g													1.50	1.40	1.31	1.24	1.17	1.11
22g														1.47	1.38	1.29	1.22	1.16
23g															1.44	1.35	1.28	1.21
24g																1.50	1.41	1.33

